REMOTE CONTROLS / PAR-CT01MA



Key Technologies





















FUNCTION	DESCRIPTION	SETTING	DISPLAY
ON/OFF	Switch between ON and OFF	0	0
Operating mode	For switching between cooling/dehum./fan/auto/heating modes Auto mode is only selectable if the indoor unit effectively offers this mode.	0	0
Temperature setting	Modify set temperature. The settable temperature range varies depending on the model of indoor unit.	0	0
Air flow direction	Modify direction of air flow. Selectable air flow directions depend on the model of indoor unit.	0	0
Swing louvre settings	Switch between swing louvre ON and OFF modes	0	0
Ventilation	Enables interlocked operation with CITY MULTI Lossnay units.	0	0
Error	Displays error with relative unit address. The following information may be displayed in the event of an error: indoor unit model, serial number, contact information (e.g. phone number of dealer). An error code may not be displayed for certain errors.	-	0
Timer	Used to set ON and OFF times. • Time settable in 5 minute steps. • Both ON and OFF times are settable. • Auto-OFF timer: Used to set Auto-Off time. • Time may be set within a range from 30 to 240 minutes in steps of 10 minutes.	0	0
Enable/disable local operations	The following functions may be disabled from specific settings on the centralised controller: ON/OFF, select operating mode, set temperature, fan speed, air flow direction, reset filter indicator lamp. The relative icon is shown on the display when a function is disabled.	×	0
Prohibited operations	May be used to disable the following functions: "Ambient", "On/Off", "Mode", "Set Temp.", "Menu", "Vent", "Louvre" or "Defl.".	0	0
Temperature range restrictions	Different settable temperature ranges may be defined for different operating modes.	0	0
Auto return	Used to force the units to operate at a preset temperature after operating for the specified period of time (time may be set within a range from 30 to 120 minutes in steps of 10 minutes). This function is not available if preset temperature ranges are limited.	0	×
Set speed	Modifies fan speed. The speeds available vary depending on the model of indoor unit installed.	0	0
Auto grille down	Automatically raises or lowers panel.	0	0
Daylight saving time	Set the daylight saving time. This function is activated in accordance with settings.	0	0
Weekly timer	Used to set weekly ON and OFF times. Time is settable in 5 minute steps. Up to eight operating patterns are available per day. Not available when Timer ON/OFF mode is active.	0	0
Night Set-back	Temperature ranges and start/end times are settable for mode.	0	0
Bluetooth®	The remote controller may be controlled from a smartphone or tablet via Bluetooth® with a dedicate app. The dedicated app may be used to send custom logos or settings to the remote control.	0	0
note controller information	For checking version of remote controller.	_	0

○ Each group × Not available